



INSTALLATION, OPERATION, & MAINTENANCE MANUAL

WITH PARTS LIST



TSP SERIES SELF PRIMING PUMP

MODEL
TSP-80

TABLE OF CONTENTS

INTRODUCTION	1
SAFETY – SECTION A	2
INSTALLATION – SECTION B	4
Pump Dimensions	4
PREINSTALLATION INSPECTION	5
POSITIONING PUMP	5
Lifting	5
Mounting	5
Clearance	5
SUCTION AND DISCHARGE PIPING	6
Materials	6
Line Configuration	6
Connections to pump	6
Gauges	6
Suction Lines	6
Fittings	6
Strainers	6
Sealing	6
Suction lines in Sump	6
Suction line Positioning	7
Discharge lines	8
Siphoning	8
Valves	8
Bypass lines	8
Automatic air release valve	8
Air release valve installation	9
Alignment	10
Coupled drives	10
V-belt drives	11
OPERATION-SECTION C	12
Priming	12
Starting	12
Rotating	12
Operation	13
Lines with a bypass	13
Lines without a bypass	13
Leakage	13
Liquid temperature and overheating	13
Strainer check	13
Pump vacuum check	14
Stopping	14
Cold weather preservation	14
Bearing temperature check	14
TROUBLESHOOTING-SECTION D	15
Preventive maintenance	18
PUMP MAINTENANCE AND REPAIR-SECTION E	19
Performance curve	19
Parts list	20

Pump model	21
Rotating assembly	22
Pump and seal disassembly and reassembly	24
Back cover and wear plate removal	24
Suction check valve removal	25

TABLE OF CONTENTS (continued)

Rotating assembly removal	25
Impeller removal	26
Shaft and bearing removal and disassembly	26
Shaft and bearing reassembly and installation	27
Seal installation	28
Impeller installation and adjustment	30
Rotating assembly installation	30
Suction check valve installation	31
Back cover installation	31
PRESSURE RELIEF VALVE	32
Final pump assembly	32
LUBRICATION	32
Seal assembly	32
Bearings	32

INTRODUCTION

Thank You for purchasing a TORO pump. **Read this manual** carefully to learn how to safely install and operate your pump. Failure to do so could result in personal injury or damage to the pump.

Because pump installations are seldom identical, this manual cannot possibly provide detailed instructions and precautions for every aspect of each specific application. Therefore, it is the responsibility of the owner/installer of the pump to ensure that applications not addressed in this manual are performed **only** after establishing that neither operator safety nor pump integrity are compromised by the installation. Pumps and related equipment **must** be installed and operated according to all national, local and industry standards.

If there are any questions regarding the pump or its application which are not covered in this manual or in other literature accompanying this unit, please contact your TORO distributor;

Global Pump Group Pty Ltd
12 Selgar Avenue, Tonsley
South Australia, 5042, AUSTRALIA
Phone: +61 8 8275 8000

For information or technical assistance on the power source, contact the power source manufacturer's local dealer or representative.

HAZARD AND INSTRUCTION DEFINITIONS


The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:



Immediate hazards which WILL result in severe personal injury or death. These instructions describe the procedure required and the injury which will result from failure to follow the procedure.



Hazards or unsafe practices which COULD result in severe personal injury or death. These instructions describe the procedure required and the injury which could result from failure to follow the procedure.



Hazards or unsafe practices which COULD result in minor personal injury or product or property damage. These instructions describe the requirements and the possible damage which could result from failure to follow the procedure.

NOTE

Instructions to aid in installation, operation, and maintenance or which clarify a procedure.

SAFETY – SECTION A

This information applies to TSP series basic pumps. TORO has no control over or knowledge of the power source which will be used. Refer to the manual accompanying the power source before attempting to begin operation.

This manual will alert personnel to known procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel. However, this manual cannot possibly provide detailed instructions and precautions for each specific application or for every situation that might occur during maintenance of the unit. Therefore, it is the responsibility of the owner, installer and/or maintenance personnel to ensure that applications and/or maintenance procedures not addressed in this manual are performed only after establishing that neither personal safety nor pump integrity are compromised by such applications or procedures.



Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Disconnect or lock out the power source to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Check the temperature before opening any covers, plates, or plugs.
5. Close the suction and discharge valves.
6. Vent the pump slowly and cautiously.
7. Drain the pump.



This pump is designed to handle liquids containing large entrained solids or slurries. Do not attempt to pump volatile, corrosive, or flammable materials which may damage the pump or endanger personnel as a result of pump failure.



Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of enough capacity and that they are positioned so that loads will be balanced, and the pump or components will not be damaged when lifting. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.



After the pump has been positioned, make certain that the pump and all piping connections are tight, properly supported and secure before operation.



Do not remove plates, covers, gauges, pipe plugs, or fittings from an over-heated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.



WARNING!

Do not operate the pump against a closed discharge valve for long periods of time. If operated against a closed discharge valve, pump components will deteriorate, and the liquid could come to a boil, build pressure, and cause the pump casing to rupture or explode.



WARNING!

Overheated pumps can cause severe burns and injuries. If overheating of the pump occurs:

1. Stop the pump immediately.
2. Ventilate the area.
3. Allow the pump to completely cool.
4. Check the temperature before opening any covers, plates, gauges, or plugs.
5. Vent the pump slowly and cautiously.
6. Refer to instructions in this manual before restarting the pump.



WARNING!

Do not operate the pump without the guards in place over the rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel.



WARNING!

Never run this pump backwards. Be certain that rotation is correct before fully engaging the pump.



CAUTION

Pumps and related equipment must be installed and operated according to all national, local and industry standards.

INSTALLATION – SECTION B

Review all SAFETY information in Section A.

Since pump installations are seldom identical, this section offers only general recommendations and practices required to inspect, position, and arrange the pump and piping.

Most of the information pertains to a standard **static lift application** where the pump is positioned above the free level of liquid to be pumped.

If installed in a **flooded suction application** where the liquid is supplied to the pump under pressure, some of the information such as

mounting, line configuration, and priming must be tailored to the specific application. Since the pressure supplied to the pump is critical to

performance and safety, **be sure** to limit the incoming pressure to **50%** of the maximum permissible operating pressure as shown on the pump performance curve.

For further assistance, contact your TORO distributor or TORO Company.

Pump Dimensions

See Figure 1 for the approximate physical dimensions of this pump.

OUTLINE DRAWING




Figure 1 - PUMP MODEL TSP-80 8"

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before shipment from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a) Inspect the pump for cracks, dents, damaged threads, and other obvious damage.
- b) Check for and tighten loose attaching hardware. Since gaskets tend to shrink after drying, check for loose hardware at mating surfaces.
- c) Carefully read all warnings and cautions contained in this manual or affixed to the pump, and perform all duties indicated. Note the direction of rotation indicated on the pump. Check that the pump shaft rotates counterclockwise when facing the impeller.



Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Refer to **Rotation in OPERATION**, Section C.

- d) Check levels and lubricate as necessary. Refer to **LUBRICATION** in the **MAINTENANCE AND REPAIR** section of this manual and perform duties as instructed.
- e) If the pump and power source have been stored for more than 12 months, some of the components or lubricants may have exceeded their maximum shelf life. These must be inspected or replaced to ensure maximum pump service.

If the maximum shelf life has been exceeded, or if anything appears to be abnormal, contact your TORO distributor or the factory to determine the repair or updating policy. Do not put the pump into service until appropriate action has been taken.

POSITIONING PUMP



Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced, and the pump or components will not be damaged when lifting. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.

Lifting

Pump unit weights will vary depending on the mounting and drive provided. Check the shipping tag on the unit packaging for the actual weight and use lifting equipment with appropriate capacity. Drain the pump and remove all customer-installed equipment such as suction and discharge hoses or piping before attempting to lift existing, installed units.

Mounting

Locate the pump in an accessible place as close as practical to the liquid being pumped. Level mounting is essential for proper operation.

The pump may have to be supported or shimmed to provide for level operation or to eliminate vibration.

Clearance

It is recommended that 18 inches (457 mm) of clearance be provided in front of the back cover to permit removal of the cover and easy access to the pump interior. A minimum clearance of 8 inches (203 mm) must be maintained to permit removal of the cover.

SUCTION AND DISCHARGE PIPING

Pump performance is adversely affected by increased suction lift, discharge elevation, and friction losses. See the performance curve and operating range show on Page 19 to be sure your overall application allows the pump to operate within the safe operation range.

Materials

Either pipe or hose may be used for suction and discharge lines; however, the materials must be compatible with the liquid being pumped. If hose is used in suction lines, it must be the rigid-wall, reinforced type to prevent collapse under suction. Using piping couplings in suction lines is not recommended.

Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

Connections to Pump

Before tightening a connecting flange, align it exactly with the pump port. Never pull a pipeline into place by tightening the flange bolts and/or couplings. Lines near the pump must be independently supported to avoid strain on the pump which could cause excessive vibration, decreased bearing life, and increased shaft and seal wear. If hose-type lines are used, they should have adequate support to secure them when filled with liquid and under pressure.

Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped, drill and tap the suction and discharge lines not less than 18" (450 mm) from the suction and discharge ports and install the lines. Installation closer to the pump may result in erratic readings.

SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

Strainers

If a strainer is furnished with the pump, be certain to use it; any spherical solids which pass through a strainer furnished with the pump will also pass through the pump itself. If a strainer is not furnished with the pump, but is installed by the pump user, make certain that the total area of the openings in the strainer is at least three or four times the cross section of the suction line, and that the openings will not permit passage of solids larger than the solids handling capability of the pump. This pump is designed to handle up to 1½" (38mm) diameter spherical solids.

Sealing

Since even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift, all connections in the suction line should be sealed with pipe dope to ensure an airtight seal. Follow the sealant manufacturer's recommendations when selecting and applying the pipe dope. The pipe dope should be compatible with the liquid being pumped.

Suction Lines in Sumps

If a single suction line is installed in a sump it should be positioned away from the wall of the sump at a distance equal to 1½ times the diameter of the suction line. If there is a liquid flow from an open pipe into the sump, the flow should be kept away from the suction inlet because the inflow will carry air down into the sump, and air entering the suction line will reduce pump efficiency.

If it is necessary to position inflow close to the suction inlet, install a baffle between the inflow and the suction inlet at a distance 1½ times the diameter of the suction pipe. The baffle will allow entrained air to escape from the liquid before it is drawn into the suction inlet.

If two suction lines are installed in a single sump, the flow paths may interact, reducing the efficiency of one or both pumps. To avoid this, position the suction inlets so that they are separated by a distance equal to at least 3 times the diameter of the suction pipe.

Suction Line Positioning

The depth of submergence of the suction line is critical to efficient pump operation. Figure 2 shows recommended minimum submergence vs. velocity.

NOTE

The pipe submergence required may be reduced by installing a standard pipe increaser fitting at the end of the suction line. The larger opening size will reduce the inlet velocity. Calculate the required submergence using the following formula based on the increased opening size (area or diameter).




Figure 2 -Recommended Minimum Suction Line Submergence vs. Velocity

DISCHARGE LINES

Siphoning

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action causing damage to the pump could result.

Valves

If a throttling valve is desired in the discharge line, use a valve as large as the largest pipe to minimize friction losses. Never install a throttling valve in a suction line.

With high discharge heads, it is recommended that a throttling valve and a system check valve be installed in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.



If the application involves a high discharge head, gradually close the discharge throttling valve before stopping the pump.

Bypass Lines

Self-priming pumps are not air compressors. During the priming cycle, air from the suction line must be vented to atmosphere on the discharge side. If the discharge line is open, this air will be vented through the discharge. However, if a check valve has been installed in the discharge line, the discharge side of the pump must be opened to atmospheric pressure through a bypass line installed between the pump discharge and the check valve. A self-priming centrifugal pump will not prime if there is sufficient static liquid head to hold the discharge check valve closed.

NOTE

The bypass line should be sized so that it does not affect pump discharge capacity; however, the bypass line should be at least 1" (25.4 mm) in diameter to minimize the chance of plugging.



In **low discharge head applications** (less than 30' or 9 meters), it is recommended that the bypass line be run back to the wet well and located 6 inches below the water level or cut-off point of the low-level pump. In some installations, this bypass line may be terminated with a six to eight-foot length of 1¼" I.D. **smooth-bore** hose; air and liquid vented during the priming process will then agitate the hose and break up any solids, grease, or other substances likely to cause clogging.



A bypass line that is returned to a wet well must be secured against being drawn into the pump suction inlet.

It is also recommended that pipe unions be installed at each 90° elbow in a bypass line to ease disassemble and maintenance.

AUTOMATIC AIR RELEASE VALVE

In **high discharge head applications** (more than 30' or 9 meters), an excessive amount of liquid may be bypassed and forced back to the wet well under the full working pressure of the pump; this will reduce overall pumping efficiency. Therefore, it is recommended that a TORO Automatic Air Release Valve be installed in the bypass line.

TORO Automatic Air Release Valves are reliable and require minimum maintenance. See AUTOMATIC AIR RELEASE VALVE in this section for installation and theory of operation of the Automatic Air Release Valve. Consult your TORO distributor for selection of an Automatic Air Release Valve to fit your application.

If the installation involves a flooded suction such as a below-ground lift station. A pipe union and manual shut - off valve may be installed in the bleed line to allow service of the valve without shutting down the station, and to eliminate the possibility of flooding. If a manual shut - off valve is installed anywhere in the air release piping, it must be a full opening ball type valve to prevent plugging by solids.

A manual shut-off valve should not be installed in any bypass line. A manual shut-off valve may inadvertently be left closed during operation. A pump which has lost prime may continue to operate without reaching prime, causing dangerous overheating and possible explosive rupture of the pump casing. Personnel could be severely injured.

Allow an overheated pump to completely cool before servicing. Do not remove plates, covers, gauges, or fittings from an overheated pump. Liquid within the pump can reach boiling temperatures, and vapor pressure within the pump can cause parts being disengaged to be ejected with great force. After the pump completely cools, drain the liquid from the pump by removing the casing drain plug. Use caution when removing the plug to prevent injury to personnel from hot liquid.

When properly installed and correctly adjusted to the specific hydraulic operating conditions of the application, the TORO Automatic Air Release Valve will permit air to

escape through the by-pass line, and then close automatically when the pump is fully primed and pumping at full capacity.



Some leakage (4 - 19 liters per minute) will occur when the valve is fully closed. Be sure the bypass line is directed back to the wet well or tank to prevent hazardous spills.

Consult the manual accompanying the Air Release Valve for additional information on valve installation and performance.

Air Release Valve Installation

The Automatic Air Release Valve must be independently mounted in a horizontal position and connected to the discharge line of the self-priming centrifugal pump (see Figure 3). The inlet opening in the Air Release Valve is equipped with standard 1-inch NPT pipe threads.




Figure 3 - Typical Automatic Air Release Valve Installation

Connect the valve outlet to a bleed line which slopes back to the wet well or sump. The bleed line must be the same size as the outlet opening or larger, depending on which Air Release Valve is being used. If piping is used for the bleed line, avoid the use of elbows whenever possible.

NOTE

It is recommended that each Air Release Valve be fitted with an independent bleeder line directed back to the wet well. If multiple Air Release Valves are installed in a system, they must be fitted with independent bleeder lines; never use a common manifold pipe. Contact your TORO distributor for information about installation of an Automatic Air Release Valve for your specific application.

ALIGNMENT

The alignment of the pump and its power source is critical for trouble-free mechanical operation. In either a flexible coupling or V-belt driven system, the driver and pump must be mounted so that their shafts are aligned with and parallel to each other. It is imperative that alignment be checked after the

pump and piping are installed, and before operation


NOTE

Check Rotation, Section C, before final alignment of the pump.

When mounted at the TORO factory, driver and pump are aligned before shipment. Misalignment will occur in transit and handling. Pumps must be checked and realigned before operation. Before checking alignment, tighten the foundation bolts. The pump casing feet and/or pedestal feet, and the driver mounting bolts should also be tightly secured.



Adjusting the alignment in one direction may alter the alignment in another direction. check each procedure after altering alignment.



Adjusting the alignment in one direction may alter the alignment in another direction. check each procedure after altering alignment.

Coupled Drives

When using couplings, the axis of the power source must be aligned to the axis of the pump shaft in both the horizontal and vertical planes. Most couplings require a specific gap or clearance between the driving and the driven shafts. Refer to the coupling manufacturer's service literature.

Align spider insert type couplings by using calipers to measure the dimensions on the circumference of the outer ends of the coupling hub every 90 degrees.

The coupling is in alignment when the hub ends are the same distance apart at all points (see Figure 4A).




Figure 4 - Aligning Spider-Type Couplings




Figure 5 - Aligning Non-Spider Type Couplings

Align non-spider type couplings by using a feeler gauge or taper gauge between the coupling halves every 90 degrees. The coupling is in alignment when the hubs are the same distance apart at all points (see Figure 5).

Check parallel adjustment by laying a straightedge across both coupling rims at the top, bottom, and side. When the straightedge rests evenly on both halves of the coupling, the coupling is in horizontal parallel alignment. If the coupling is misaligned, use a feeler gauge between the coupling and the straightedge to measure the amount of misalignment.

V-Belt Drives

When using V-belt drives, the power source and the pump must be parallel. Use a straightedge along the sides of the pulleys to ensure that the pulleys are properly aligned (see Figure 4). In drive systems using two or more belts, make certain that the belts are a matched set; unmatched sets will cause accelerated belt wear.




Figure 6 - Aligning Non-Spider Type Couplings

Tighten the belts in accordance with the belt manufacturer's instructions. If the belts are too loose, they will slip; if the belts are too tight, there will be excessive power loss and possible bearing failure. Select pulleys that will match the proper speed ratio; over-speeding the pump may damage both pump and power source.



WARNING!

Do not operate the pump without the guard in place over the rotating parts, exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel.

OPERATION – SECTION C

Review all SAFETY information in Section A.

Follow the instructions on all tags, labels and decals attached to the pump.



WARNING!

This pump is designed to handle sewage, wastewater, trash and slurries containing large entrained solids. Do not attempt to pump volatile, corrosive, or flammable materials which may damage the pump or endanger personnel as a result of pump failure.



CAUTION

Pump speed and operating condition points must be within the continuous performance range shown on the curve.

PRIMING

Install the pump and piping as described in **INSTALLATION**. Make sure that the piping connections are tight, and that the pump is securely mounted. Check that the pump is properly lubricated (see **LUBRICATION** in **MAINTENANCE AND REPAIR**).

This pump is self-priming, but the pump should never be operated unless there is liquid in the pump casing.



CAUTION

Never operate this pump unless there is liquid in the pump casing. The pump will not prime when dry. Extended operation of a dry pump will destroy the seal assembly.

Add liquid to the pump casing when:

1. The pump is being put into service for the first time.
2. The pump has not been used for a considerable length of time.
3. The liquid in the pump casing has evaporated.

Continue to circulate through the bypass line while the pump is in operation.



CAUTION

Once the pump casing has been filled, the pump will prime and re-prime as necessary.



WARNING!

After filling the pump casing, reinstall the fill cover assembly and tighten the clamp bar screw and machine bolts (14 and 15). Do

not attempt to operate the pump unless all connecting piping is securely installed. Otherwise, liquid in the pump forced out under pressure could cause injury to personnel.

To fill the pump, remove the pump casing fill cover in the top of the casing, and add clean liquid until the casing is filled. Replace the fill cover before operating the pump.

STARTING

Consult the operations manual furnished with the power source.

Rotation

The correct direction of pump rotation is counterclockwise when facing the impeller. The pump could be damaged, and performance adversely affected by incorrect rotation. If pump performance is not within the specified limits (see the curve on page 19), check the direction of power source rotation before further troubleshooting.



CAUTION

If an electric motor is used to drive the pump, remove V - belts, couplings, or otherwise disconnect the pump from the motor before checking motor rotation. Operate the motor independently while

observing the direction of the motor shaft, or cooling fan. If rotation is incorrect on a three-phase motor, have a qualified electrician interchange any two of the three phase wires to change direction. If rotation is incorrect on a single-phase motor, consult the literature supplied with the motor for specific instructions.

OPERATION

Lines with a Bypass

If a TORO Automatic Air Release Valve has been installed, the valve will automatically open to allow the pump to prime, and automatically close after priming is complete (see **INSTALLATION** for Air Release Valve operation).

If the bypass line is open, air from the suction line will be discharged through the bypass line back to the wet well during the priming cycle. Liquid will then

Lines Without a Bypass

Open all valves in the discharge line and start the power source. Priming is indicated by a positive reading on the discharge pressure gauge or by a quieter operation. The pump may not prime immediately because the suction line must first fill with liquid. If the pump fails to prime within five minutes, stop it and check the suction line for leaks.

After the pump has been primed, partially close the discharge line throttling valve in order to fill the line slowly and guard against excessive shock pressure which could damage pipe ends, gaskets, sprinkler heads, and any other fixtures connected to the line. When the discharge line is completely filled, adjust the throttling valve to the required flow rate.



Do not operate the pump against a closed discharge throttling valve for long periods of time. If operated against a closed discharge throttling valve, pump components will deteriorate, and the liquid could come to a boil, build pressure, and cause the pump casing to rupture or explode.

Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

Liquid Temperature and Overheating

The maximum liquid temperature for this pump is 160°F (71°C). Do not apply it at a higher operating temperature.

Overheating can occur if operated with the valves in the suction or discharge lines closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump and allow it to completely cool before servicing it. Refill the pump casing with cool liquid.



Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to completely cool before servicing.

As a safeguard against rupture or explosion due to heat, this pump is equipped with a pressure relief valve which will open if vapor pressure within the pump casing reaches a critical point. If overheating does occur, stop the pump immediately and allow it to cool before servicing it. Approach any overheated pump cautiously. It is recommended that the pressure relief valve assembly be replaced at each overhaul, or any time the pump casing overheats and activates the valve. Never replace this valve with a substitute which has not been specified or provided by the TORO Company.

Strainer Check

If a suction strainer has been shipped with the pump or installed by the user, check the strainer regularly, and clean it as necessary. The strainer should also be checked if pump flow rate begins to drop. If a vacuum suction gauge has been installed, monitor and record the readings regularly to detect strainer blockage.

Never introduce air or steam pressure into the pump casing or piping to remove a blockage. This could result in personal injury or damage to the equipment. If back flushing is necessary, liquid pressure must be limited to 50% of the maximum permissible operating pressure shown on the pump performance curve.

Pump Vacuum Check


With the pump inoperative, install a vacuum gauge in the system, using pipe dope on the threads. Block the suction line and start the pump. At operating speed, the pump should pull a vacuum of 20" (508 mm) or more of mercury. If it does not, check for air leaks in the seal, gasket, or discharge valve.

Open the suction line and read the vacuum gauge with the pump primed and at operation speed. Shut off the pump. The vacuum gauge reading will immediately drop proportionate to static suction lift and should then stabilize. If the vacuum reading falls off rapidly after stabilization, an air leak exists. Before checking for the source of the leak, check the point of installation of the vacuum gauge.

STOPPING

Never halt the flow of liquid suddenly. If the liquid being pumped is stopped abruptly, damaging shock waves can be transmitted to the pump and piping system. Close all connecting valves slowly.

On engine driven pumps, reduce the throttle speed slowly and allow the engine to idle briefly before stopping.



If the application involves a high discharge head, gradually close the discharge throttling valve before stopping the pump.

After stopping the pump, disconnect or lock out the power source or take other action to ensure that the pump will remain inoperative.



Do not operate the pump against a closed discharge throttling valve for long periods of time. If operated against a closed discharge throttling valve, pump components will deteriorate, and the liquid could come to a boil, build pressure, and cause the pump casing to rupture or explode.

Cold Weather Preservation

In below freezing conditions, drain the pump to prevent damage from freezing. Also, clean out any solids by flushing with a hose. Operate the pump for approximately one minute; this will remove any remaining liquid that could freeze the pump rotating parts. If the pump will be idle for more than a few hours, or if it has been pumping liquids containing many solids, drain the pump, and flush it thoroughly with clean water. To prevent large solids from clogging the drain port and preventing the pump from completely draining, insert a rod or stiff wire in the drain port, and agitate the liquid during the draining process. Clean out any remaining solids by flushing with a hose.

BEARING TEMPERATURE CHECK

Bearings normally run at higher than ambient temperatures because of heat generated by friction. Temperatures up to 160°F (71°C) are considered normal for bearings, and they can operate safely to at least 180°F (82°C).

Checking bearing temperatures by hand is inaccurate. Bearing temperatures can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperature is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see **LUBRICATION in MAINTENANCE AND REPAIR**). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Continued operation should bring the temperatures down to normal levels.

TROUBLESHOOTING – SECTION D

Review all SAFETY information in Section A.



Before attempting to open or service the pump:

- 1. Familiarize yourself with this manual.**
- 2. Disconnect or lock out the power source or take other action to ensure that the pump will remain inoperative.**
- 3. Allow the pump to completely cool if overheated.**
- 4. Vent the pump slowly and cautiously.**
- 5. Close the suction and discharge valves.**
- 6. Check the temperature before opening any covers, plates, or plugs.**
- 7. Drain the pump.**

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP FAILS TO PRIME	Not enough liquid in casing.	Add liquid to casing. See PRIMING .
	Suction check valve contaminated or damaged.	Clean or replace check valve.
	Air leak in suction line.	Correct leak.
	Lining of suction hose collapsed.	Replace suction hose.
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.
	Suction lift or discharge head too high.	Check piping installation and install bypass line if needed. See INSTALLATION .
	Strainer clogged.	Check strainer and clean if necessary.
PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE	Air leak in suction line.	Correct leak.
	Lining of suction hose collapsed.	Replace suction hose.
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.
	Strainer clogged.	Check strainer and clean if necessary.

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE	<p>Strainer clogged.</p> <p>Suction intake not submerged at proper level or sump too small.</p> <p>Impeller or other wearing parts worn or damaged.</p> <p>Impeller clogged.</p> <p>Discharge head too high.</p> <p>Suction lift too high.</p> <p>Pump speed too slow.</p>	<p>Check strainer or clean if necessary.</p> <p>Check installation and correct submergence as needed.</p> <p>Replace worn or damaged parts. Check that impeller is properly centered and rotates freely.</p> <p>Free impeller of debris.</p> <p>Install bypass line.</p> <p>Measure lift w/vacuum gauge. Reduce lift and/or friction losses in suction line.</p> <p>Check engine output; consult engine operation manual.</p>
PUMP REQUIRES TOO MUCH POWER	<p>Pump speed too high.</p> <p>Discharge head too low.</p> <p>Liquid solution too thick.</p> <p>Bearing(s) frozen.</p>	<p>Check engine output. check that sheaves or couplings are correctly sized</p> <p>Adjust discharge valve.</p> <p>Dilute if possible.</p> <p>Disassemble pump and check bearing(s).</p>
PUMP CLOGS FREQUENT LY	<p>Discharge flow too slow.</p> <p>Suction check valve or foot valve clogged or binding.</p> <p>Liquid solution too thick.</p>	<p>Open discharge valve fully to increase flow rate and run engine at maximum governed speed.</p> <p>Clean valve.</p> <p>Dilute if possible.</p>

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
EXCESSIVE NOISE	<p>Cavitation in pump.</p> <p>Pumping entrained air.</p> <p>Pump or drive not securely mounted.</p> <p>Impeller clogged or damaged.</p>	<p>Reduce suction lift and/or friction losses in suction line. Record vacuum and pressure gauge readings and consult local representative or factory.</p> <p>Locate and eliminate source of air bubble.</p> <p>Secure mounting hardware.</p> <p>Clean out debris; replace damaged parts.</p>
BEARINGS RUN TOO HOT	<p>Bearing temperature is high, but within limits.</p> <p>Low or incorrect lubricant.</p> <p>Suction and discharge lines not properly supported.</p> <p>Drive misaligned.</p>	<p>Check bearing temperature regularly to monitor any increase.</p> <p>Check for proper type and level of lubricant.</p> <p>Check piping installation for proper support.</p> <p>Align drive properly.</p>

PREVENTIVE MAINTENANCE

Since pump applications are seldom identical, and pump wear is directly affected by such things as the abrasive qualities, pressure and temperature of the liquid being pumped, this section is intended only to provide general recommendations and practices for preventive maintenance. Regardless of the application however, following a routine preventive maintenance schedule will help assure trouble free performance and long life from your TORO pump. For specific questions concerning your application, contact your TORO distributor or the TORO Company.

Record keeping is an essential component of a good preventive maintenance program. Changes in suction and discharge gauge readings (if so equipped) between


regularly scheduled inspections can indicate problems that can be corrected before system damage or catastrophic failure occurs. The appearance of wearing parts should also be documented at each inspection for comparison as well. Also, if records indicate that a certain part (such as the seal) fails at approximately the same duty cycle, the part can be checked and replaced before failure occurs, reducing unscheduled downtime. For new applications, a first inspection of wearing parts at 250 hours will give insight into the wear rate for your application. Subsequent inspections should be performed at the intervals shown on the chart below. Critical applications should be inspected more frequently.

Preventive Maintenance Schedule					
Item	Service Interval*				
	Daily	Weekly	Monthly	Semi Annually	Annually
General Condition (Temperature, Unusual Noises or Vibrations, Cracks, Leaks, Loose Hardware, Etc.)	I				
Pump Performance (Gauges, Speed, Flow)	I				
Bearing Lubrication		I			R
Seal Lubrication (And Packing Adjustment, If So Equipped)		I			
V-Belts (If So Equipped)			I		
Air Release Valve Plunger Rod (If So Equipped)			I	C	
Front Impeller Clearance (Wear Plate)					
Rear Impeller Clearance (Seal Plate)				I	
Check Valve				I	
Pressure Relief Valve (If So Equipped)					C
Pump and Driver Alignment					I
Shaft Deflection					I
Bearings					I
Bearing Housing					I
Piping					I
Driver Lubrication – See Mfg.'s Literature					
Legend: I = Inspect, Clean, Adjust, Repair or Replace as Necessary C = Clean R = Replace Service interval based on an intermittent duty cycle equal to approximately 4000 hours annually. Adjust schedule as required for lower or higher duty cycles or extreme operating conditions.					

PUMP MAINTENANCE AND REPAIR – SECTION E

Maintenance and repair of the wearing parts of the pump will maintain peak operating performance.

PERFORMANCE CURVE



STANDARD PERFORMANCE FOR PUMP MODEL TSP-80 8"

Based on 70°F (21°C) clear water at sea level with minimum suction lift. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.



Pump speed and operating condition points must be within the continuous performance range shown on the curve.




Figure 7 - Pump Model TSP-80 8"

PARTS LIST

Pump Model TSP-80 8"

ITEM	PART NAME	PART NUMBER	MATERIAL	QTY	ITEM	PART NAME	PART NUMBER	MATERIAL	QTY
1	HEX HD CAP SCREW	001.TSP80.600	CARBON STEEL	8	23	PIPE PLUG	023.TSP80.600	CARBON STEEL	1
2	SPRING WASHER	002.TSP80.600	CARBON STEEL	8	24	DISCHARGE FLANGE	024.TSP80.010	GREY CAST IRON	1
3	PIPE PLUG	003.TSP80.600	CARBON STEEL	1	25	GSKT, DISCH FLANGE	025.TSP80.381	NITRILE*	1
4	SUCTION FLANGE	004.TSP80.010	GREY CAST IRON	1	26	PIPE PLUG	026.TSP80.600	CARBON STEEL	1
5	CHECK VALVE PIN	005.TSP80.123	304SS	1	27	LIFTING BOLT	027.TSP80.600	CARBON STEEL	1
6	PIPE PLUG	006.TSP80.600	CARBON STEEL	1	28	PUMP CASING	028.TSP80.010	GREY CAST IRON	1
7	SUCTION FLANGE GSKT	007.TSP80.381	NITRILE*	1	29	HEX HD CAP SCREW	029.TSP80.600	CARBON STEEL	4
8	PIVOT CAP	008.TSP80.123	304SS	1	30	SPRING WASHER	030.TSP80.600	CARBON STEEL	4
9	CHECK VALVE	009.TSP80.381	NITRILE*	1	31	COVER PLATE HANDLE	031.TSP80.600	WCB	2
10	BRONZE PIPE	010.TSP80.601	BRONZE	2	32	LIFTING BOLT	032.TSP80.600	CARBON STEEL	2
11	WASHER, PIVOT CAP	011.TSP80.123	304SS	1	33	PRESS RELE VALVE	033.TSP80.602	BRASS	1
12	SPRING WASHER	012.TSP80.123	304SS	2	34	HAND NUT	034.TSP80.600	WCB	4
13	HEX HD CAPSCREW	013.TSP80.123	304SS	2	35	STUD	035.TSP80.600	CARBON STEEL	4
14	MACHINE BOLT	014.TSP80.600	CARBON STEEL	2	36	BACK COVER PLATE	036.TSP80.010	GREY CAST IRON	1
15	CLAMP BAR SCREW	015.TSP80.600	WCB	1	37	HAND NUT	037.TSP80.123	304SS	3
16	CLAMP BAR	016.TSP80.015	DUCTILE IRON	1	38	SPRING WASHER	038.TSP80.123	304SS	3
17	FILL COVER	017.TSP80.015	DUCTILE IRON	1	39	STUD	039.TSP80.123	304SS	3
18	GSKT, FILL COVER	018.TSP80.381	NITRILE*	1	40	O-RING	040.TSP80.381	NITRILE*	1
19	PIPE PLUG	019.TSP80.600	CARBON STEEL	1	41	O-RING	041.TSP80.381	NITRILE*	1
20	HEX HD CAPSCREW	020.TSP80.600	CARBON STEEL	8	42	WEAR PLATE ASSY	042.TSP80.600	CARBON STEEL**	1
21	SPRING WASHER	021.TSP80.600	CARBON STEEL	8	43	PIPE PLUG	043.TSP80.600	CARBON STEEL**	1

* Parts may also be supplied in Viton material **Parts may also be supplied in SS304 and SS316 Material

ROTATING ASSEMBLY

ITEM	PART NAME	PART NUMBER	MATERIAL	QTY	ITEM	PART NAME	PART NUMBER	MATERIAL	QTY
44	BEARING HOUSING	044.TSP80.381	NITRILE	1	63	FLAT WASHER	063.TSP80.600	CARBON STEEL	6
45	PIPE PLUG	045.TSP80.600	CARBON STEEL	1	64	ADAPTER RING	064.TSP80.123	304SS	1
46	AIR VENT PLUG	046.TSP80.602	BRASS	1	65	HEX NUT	065.TSP80.600	CARBON STEEL	3
47	SOCKET HD CAP SCREW	047.TSP80.123	304SS	1	66	HEX HD CAPSCREW	066.TSP80.600	CARBON STEEL	3
48	Impeller Washer	048.TSP80.123	304SS	1	67	SPRING WASHER	067.TSP80.600	CARBON STEEL	6
49	IMPELLER	049.TSP80.015	DUCTILE IRON**	1	68	HEX HD CAPSCREW	068.TSP80.600	CARBON STEEL	6
50	IMPELLER ADJ SHIM SET	050.TSP80.123	304SS	7	69	SPRING WASHER	069.TSP80.600	CARBON STEEL	6
51	MECH. SEAL ASSY	051.TSP80.118	316SS	1	70	HEX HD CAPSCREW	070.TSP80.600	CARBON STEEL	6
52	O-RING	052.TSP80.381	NITRILE*	1	71	INBOARD BALL BEARING	071.TSP80.000	NA	1
53	SEAL PLATE	053.TSP80.010	GREY CAST IRON	1	72	SHAFT	072.TSP80.603	4140.00	1
54	SEAL PLATE GSKT	054.TSP80.545	ARAMID FIBRES	1	73	OUTBOARD BALL BEARING	073.TSP80.000	NA	1
55	OIL SEAL, INBOARD	055.TSP80.600	CARBON STEEL	1	74	SHAFT KEY	074.TSP80.123	304SS	1
56	OIL SEAL, INBOARD	056.TSP80.600	CARBON STEEL	1	75	BRG SNAP RING	075.TSP80.600	CARBON STEEL	1
57	O-RING	057.TSP80.381	NITRILE	1	76	O-RING	076.TSP80.381	NITRILE	1
58	SPRING WASHER	058.TSP80.600	CARBON STEEL	4	77	BEARING COVER, INBOARD	077.TSP80.010	GREY CAST IRON	1
59	HEX HD CAP SCREW	059.TSP80.600	CARBON STEEL	4	78	OUTBOARD OIL SEAL	078.TSP80.600	CARBON STEEL	1
60	PIPE PLUG	060.TSP80.600	CARBON STEEL	2	79	SPRING WASHER	079.TSP80.600	CARBON STEEL	6
61	SIGHT GAUGE	061.TSP80.123	304SS	2	80	CAPSCREW	080.TSP80.600	CARBON STEEL	6
62	PIPE PLUG	062.TSP80.600	CARBON STEEL	1	62				

* Parts may also be supplied in Viton material **Parts may also be supplied in SS304 and SS316 Material

ILLUSTRATION




Figure 8 - Repair Rotating Assembly

ITEM NO.	PART NAME	MAT' L	QTY
1	IMPELLER	DUCTILE IRON	1
2	SEAL ASSEMBLY	S-S-V-316-630	1
3	ADJ SHIM SET	304ss	2-5
4	OIL SEAL	TC	1
5	SEAL PLATE	CAST IRON	1
6	GASKET	ARAMID FIBERS	1
7	OIL SEAL	TC	1
7A	OIL SEAL	TC	1
8A/8B	DRAIN PLUG	CARBON STEEL	2
9	BEARING HOUSING	CAST IRON	1
10	VENTED PIPE PLUG	CARBON STEEL	
11	AIR VENT	BRASS	1
14	SIGHT GAUGE	304SS	1
14A	SIGHT GAUGE	304SS	1
15	HEX HD CAPSCREW	CARBON STEEL	4
16	LOCKWASHER	CARBON STEEL	4
17	HEX HD CAPSCREW	CARBON STEEL	6
18	LOCK WASHER	CARBON STEEL	6
19	BEARING CAP	CAST IRON	1
20	O RING	NBR	1
21	RETAINING RING	/	1
22	BEARING	/	1
23	KEY	304SS	1
24	SHAFT	4140	1
25	BEARING	/	1
26	SOCK HEAD CAP SCREW	304SS	1
27	IMPELLER WASHER	304SS	1
28	O RING	NBR	2
29	PIPE PLUG	CARBON STEEL	1
30	ROTATE DIRECTION STICKER	/	1

PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

Review all SAFETY information in Section A.

Follow the instructions on all tags, label and decals attached to the pump.

This pump requires little service due to its rugged, minimum maintenance design. However, if it becomes necessary to inspect or replace the wearingparts, follow these instructions which are keyed to the exploded and sectional views (see Figures 7 and 8) and the accompanying parts lists.

This manual will alert personnel to known procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel. However, this manual cannot possibly anticipate and provide detailed precautions for every situation that might occur during maintenance of the unit. Therefore, it is the responsibility of the owner/maintenance personnel to ensure that only safe, established maintenance procedures are used, and that any procedures not addressed in this manual are performed only after establishing that neither personal safety nor pump integrity are compromised by such practices.

Many service functions may be performed by draining the pump and removing the suction head. If major repair is required, the piping and/or engine must be disconnected. The following instructions assume complete disassembly is required.

Before attempting to service the pump, disconnect or lock out the power source and take precautions to ensure that it will remain inoperative. Close all valves in the suction and discharge lines.

For power source disassembly and repair, consult the literature supplied with the power source, or contact your local power source representative.



Before attempting to open or service the pump:

- 1. Familiarize yourself with this manual.**
- 2. Disconnect or lock out the power source to ensure that the pump will remain inoperative.**
- 3. Allow the pump to completely cool if overheated.**
- 4. Check the temperature before opening any covers, plates, or plugs.**
- 5. Close the suction and discharge valves.**
- 6. Vent the pump slowly and cautiously.**
- 7. Drain the pump.**



Use lifting and moving equipment in good repair and with adequate capacity to prevent injuries to personnel or damage to equipment. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.

Back Cover and Wear Plate Removal (Figure 7)

The wear plate (41) is easily accessible and may be serviced by removing the back-cover plate (36). Before attempting to service the pump, remove the pump casing drain plug (42) and drain the pump. Clean and reinstall the drain plug.

Remove the hand nuts (33), remove the back cover and assembled wear plate from the pump casing (28). Inspect the wear plate and replace it if badly scored or worn. To remove the wear plate, disengage the hardware (37,38 and 39).

Inspect the back-cover O-ring (40) and replace it if damaged or worn.

Suction Check Valve Removal

If the check valve assembly (assemble 8,9,10,11,12 and 13) is to be serviced, removed the hardware (1and 2) and the check valve pin (5), pull the complete check valve assembly from the suction flange (3).

NOTE

Further disassembly of the check valve is not required since it must be replaced as a complete unit. Individual parts are not sold separately.

Rotating Assembly Removal

The rotating assembly may be serviced without disconnecting the suction or discharge piping; however, the power source must be removed to provide clearance.

The impeller (47) should be loosened while the rotating assembly is still secured to the pump casing. Before loosening the impeller, remove the seal cavity drain plug (57) and drain the seal lubricant. This will prevent the oil in the seal cavity from escaping when the impeller is loosened. Clean and reinstall the seal cavity drain plug.

Immobilize the impeller by wedging a block wood between the vanes and the pump casing and remove the impeller cap screw and washer (45 and 46). Install the shaft key (63). Install a lathe dog on the drive end of the shaft (62) with the "V" notch positioned over the shaft key.

With the impeller rotation still blocked, see Figure E-3 and use a long piece of heavy bar stock to pry against the arm of the lathe dog in a counterclockwise direction (when facing the drive end of the shaft). Use caution not to damage the shaft or keyway. When the impeller breaks loose, remove the lathe dog, key and wood block.

NOTE

Do not remove the impeller until the rotating assembly has been removed from the pump casing.

Remove the inner hardware (67 and 68) from the casing ring (64). Install three of the inner cap-screws in the jacking holes in the casing ring and use them to press the rotating assembly into the pump casing until the bearing housing is free.

Remove the jacking screws from the casing ring. Remove the outer hardware (69 and 70) and shims (63) and separate the casing ring from the pump casing. Tie and tag the shim sets for ease of reassembly.

An optional disassembly tool for removing and installing the rotating assembly is available from the factory. If the tool is used, follow the instructions

packed with it. If improvised tools are used, be sure they are heavy enough for safe use and will not damage the pump.

After the rotating assembly is loosened, screw a 5/8-18 UNF X 16-inch long threaded rod into the impeller shaft. Support the drive end with another set of handles or a length of pipe (1-13/16 inch [46 mm] minimum I.D.) and slide the complete rotating assembly through the back-cover opening. Move the rotating assembly to a cleanwork area before proceeding with disassembly. Remove the seal plate and bearing housing O-rings(57).




Figure 9 -Loosening Impeller





Figure 10 - Rotating Assembly Removal

Impeller Removal

With the rotating assembly removed from the pump casing, unscrew the impeller from the shaft. Use caution when unscrewing the impeller; tension on the shaft seal spring will be released as the impeller is removed. Inspect the impeller and replace if cracked or badly worn.

Remove the impeller adjusting shims (3); tie and tag the shims, or measure and record their thickness for ease of reassembly.

Seal Removal

Slide the shaft sleeve and rotating portion of the seal off the shaft as a unit.

Use a pair of stiff wires with hooked ends to remove the stationary element and seat.

An alternate method of removing the stationary seal components is to remove the hardware (15 and 16) and separate the seal plate (5) and gasket (6) from the bearing housing (9). Position the seal plate on a flat surface with the impeller side down. Use a wooden dowel or other suitable tool to press on the back side of the stationary seat until the seat, O-rings, and stationary element can be removed.

Installation. Shaft and Bearing Removal and Disassembly

When the pump is properly operated and maintained, the bearing housing should not require disassembly. Disassemble the shaft and bearings only when there is evidence of wear or damage.



Shaft and bearing disassembly in the field is not recommended. These operations should be performed only in a properly equipped shop by qualified personnel.

Remove the bearing housing drain plug (57) and drain the lubricant. Clean and reinstall the drain plug.

Disengage the hardware (69 and 70) and slide the bearing cap (67) and oil seal (68) off the shaft (62). Remove the bearing cap gasket (66) and press the oil seal from the bearing cap.

Place a block of wood against the impeller end of the shaft and tap the shaft and assembled bearings (61 and 64) from the bearing housing.

After removing the shaft and bearings, clean and inspect the bearings **in place** as follows.

Shaft and Bearing Reassembly and Installation

Clean the bearing housing, shaft and all component parts (except the bearings) with a soft cloth soaked in cleaning solvent. Inspect the parts for wear or damage as necessary.




To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected in place. It is strongly recommended that the bearings be replaced any time the shaft and bearings are removed.

Clean the bearing housing, shaft and all component parts (except the bearings) with a soft cloth soaked in cleaning solvent. Inspect the parts for wear or damage and replace as necessary.



Most cleaning solvents are toxic and flammable. Use them only in a well-ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Clean the bearings thoroughly in fresh cleaning solvent. Dry the bearings with filtered compressed air and coat with light oil.



Bearings must be kept free of all dirt and foreign material. Failure to do so will greatly shorten bearing life. Do not spin dry bearings. This may scratch the balls or races and cause premature bearing failure.

Rotate the bearings by hand to check for roughness or binding and inspect the bearing balls. If rotation is rough or the bearing balls are discolored, replace the bearings.

The bearing tolerances provide a tight press fit onto the shaft and a snug slip fit into the bearing housing. Replace the bearings, shaft, or bearing housing if the proper bearing fit is not achieved.

If bearing replacement is required, remove the outboard bearing retaining ring (65) and use a bearing puller to remove the bearings from the shaft.



Most cleaning solvents are toxic and flammable. Use them only in a well-ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Inspect the shaft for distortion, nicks or scratches, or for thread damage on the impeller end. Dress small nicks and burrs with a fine file or emery cloth. Replace the shaft if defective.

Position the inboard oil seal (52) in the bearing housing bore with the lip positioned. Press the oil seal into the housing until the face is just flush with the machined surface on the housing.



To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected in place. It is strongly recommended that the bearings be replaced any time the shaft and bearings are removed.

NOTE

Position the inboard bearing (61) on the shaft with the shielded side toward the impeller end of the shaft. Position the outboard bearing (64) on the shaft with the integral retaining ring on the bearing O.D. toward the drive end of the shaft.




Figure 11 - INBOARD BEARING POSITIONING

The bearings may be heated to ease installation. An induction heater, hot oil bath, electric oven, or hot plate may be used to heat the bearings. Bearings should never be heated with a direct flame or directly on a hot plate.

NOTE

If a hot oil bath is used to heat the bearings, both the oil and the container must be clean. If the oil has been previously used, it must be thoroughly filtered.

Heat the bearings to a uniform temperature **no higher** than 250°F (120°C), and slide the bearings onto the shaft, one at a time, until they are fully seated. This should be done quickly, in one continuous motion, to prevent the bearings from cooling and sticking on the shaft.

NOTE



Position the inboard bearing (25) on the shaft as indicated by the above illustration.

After the bearings have been installed and allowed to cool, check to ensure that they have not moved away from the shaft shoulders in shrinking. If movement has occurred, use a suitably sized sleeve and a press to reposition the bearings against the shaft shoulders.

If heating the bearings is not practical, use a suitably sized sleeve and an arbor (or hydraulic) press to install the bearings on the shaft.



When installing the bearings onto the shaft, never press or hit against the outer race, balls, or ball cage. Press only on the inner race. Never hit the balls or ball cage.



Press the outboard oil seal (68) into the bearing cap (67) with the lip positioned as shown in Figure 11. Replace the bearing cap gasket (66) and secure the bearing cap with the hardware (69 and 70). Be careful not to damage the oil seal lip on the shaft keyway.

Lubricate the bearing housing as indicated in **LUBRICATION**.

Seal Installation
(Figures 8 and 10)



Most cleaning solvents are toxic and flammable. Use them only in a well-ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Clean the seal cavity and shaft with a cloth soaked in fresh cleaning solvent. Inspect the stationary seat bore in the seal plate for dirt, nicks and burrs, and remove any that exist. The stationary seat bore must be completely clean before installing the seal.

A new seal assembly should be installed any time the old seal is removed from the pump. Wear patterns on the finished faces cannot be realigned during reassembly. Reusing an old seal could result in premature failure.

Handle the seal parts with extreme care to prevent damage. Be careful not to contaminate precision finished faces; even fingerprints on the faces can shorten seal life. If necessary, clean the faces with a non-oil-based solvent and a clean, lint-free tissue. Wipe lightly in a concentric pattern to avoid scratching the faces.

If a replacement seal is being used, remove it from the container and inspect the precision finished faces to ensure that they are free of any foreign matter.

To ease installation of the seal, lubricate the O-rings with water or a very small amount of oil and apply a

drop of light lubricating oil on the finished faces. Assemble the seal as follows (see Figure 12).





Figure 12 -Seal Assembly



This seal is not designed for operation at temperatures above 160°F (71°C). Do not use at higher operating temperatures.

Lubricate the stationary seat O-rings with water or light oil and install them in the stationary seat. Install the stationary seal element in the stationary seat. Press this stationary subassembly into the front of the seal plate (5) until it seats squarely against the bore shoulder.

Install the seal plate gasket (6). Position the seal plate and stationary seat over the shaft and secure it to the bearing housing (9) with the hardware (15 and 16). Be careful not to damage the stationary element on the shaft threads.

NOTE

It is recommended that a tapered sleeve be installed over the threads of the impeller shaft to ease installation of the rotating seal components.

Lubricate the shaft with water or a **small** amount of light oil and slide the rotating subassembly (consisting of the rotating element, bellows and retainer) onto the shaft. Apply firm, steady pressure on the seal retainer as it slides onto the shaft until the seal faces contact.

Install the seal spring. Lubricate the seal as indicated in **LUBRICATION** after the impeller is installed.

Impeller Installation and Adjustment

Inspect the impeller and replace it if cracked or badly worn. Inspect the impeller and shaft threads for dirt or damage, and clean or dress the threads as required.



The shaft and impeller threads must be completely clean before reinstalling the impeller. Even the slightest amount of dirt on the threads can cause the impeller to seize to the shaft, making future removal difficult or impossible without damage to the impeller or shaft.

Install the same thickness of impeller adjusting shims (3) as previously removed. Apply 'Never-Seez' or equivalent to the shaft threads and screw the impeller onto the shaft until tight. Be sure the seal spring seats squarely on the back side of the impeller.

NOTE

At the slightest sign of binding, immediately back the impeller off, and check the threads for dirt. Do not try to force the impeller onto the shaft.

A clearance of .025 to .040 inch (0,64 to 1,02 mm) between the impeller and the seal plate is recommended for maximum pump efficiency. Measure this clearance and add or remove impeller adjusting shims as required.

NOTE

If the rotating assembly has been installed in the pump casing, this clearance may be measured by reaching through the priming port with a feeler gauge.

Proceed with Rotating Assembly Installation before installing the impeller cap screw and washer (26 and 27). The rotating assembly must be installed in the pump casing in order to torque the impeller cap screw.

Rotating Assembly Installation

Install the bearing housing and seal plate O-rings (52) and lubricate them with light grease. Slide the rotating assembly into the pump casing using the installation tool. **Be careful** not to damage the O-rings.

Install the pump casing ring (64) and secure it to the rotating assembly with the inner hardware (67 and 68).

NOTE

The inner cap screws are 1/4 inch (3,2 mm) shorter than the outer cap screws

Install the rotating assembly shims (63) under the pump casing ring and secure the ring to the pump casing with the outer hardware (69 and 70).

To set the impeller and wear plate clearance, refer to the **Back-Cover Installation and Adjustment**.

Suction Check Valve Installation

Inspect the check valve assembly (6-13) and replace it if badly worn.

NOTE

The check valve assembly must be replaced as a complete unit. Individual parts are not sold separately. After the rotating assembly is installed in the pump casing, coat the threads of the impeller cap screw (26) with 'Never-Seez' or equivalent compound, and install the impeller washer (27) and cap screw; torque the cap screw to 90 ft. lbs. (1080 in. lbs. or 12,4 m. kg.).

Reach through the back cover opening with the check valve and position the check valve adaptor in the mounting slot in the suction flange (4). Align the adaptor with the flange hole and secure the assembly with the check valve pin (5).

NOTE

If the suction or discharge flanges were removed, replace the respective gaskets, apply 'Permatex Aviation No. 3 Form-A-Gasket' or equivalent compound to the mating surfaces, and secure them to the pump casing with the attaching hardware

Back Cover Installation and Adjustment

If the wear plate (42) was removed for replacement, carefully center it on the back cover and secure it with the hardware (37 and 38). The wear plate **must** be concentric to prevent binding when the back cover is installed.

Clearance between the impeller and wear plate is adjusted using four adjusting screws and locking collars. There are 18 detents on the I.D. of each locking collar. Indexing the collars one detent on the adjusting screws represents approximately .005 inch (0,13 mm) of wear plate clearance. The recommended clearance between the wear plate and the impeller is .010 to .020 inch (0,25 to 0,50 mm).

Replace the back-cover O-rings (40 and 10) and lubricate them with a generous amount of No. 2 grease. Clean any scale or debris from the contacting surfaces in the pump casing that might interfere or prevent a good seal with the back cover.

Screw the adjusting screws (32) into the tapped holes in the back-cover plate until they are **just flush** with the machined surface on the back side of the cover plate.

Align the back-cover plate over the studs (35) and slide it into the pump casing. Use adjusting screws (32) to press the back cover into the pump casing until the wear plate **just touches** the impeller when the shaft is turned by hand. **Tighten the back-cover nuts evenly to avoid binding.**




Figure 13 - Installing and Adjusting Back Cover

With the wear plate just touching the impeller, slightly loosen the hand nuts. Slowly tighten two eye bolts (32) into the tapped holes in the back-cover plate. Here comes to use the dial indicator. The dial indicator is attached to the pump casing (28) with the indicator button/ probe resting on the front face of the back-cover plate (36), measuring the clearance between the wear plate and the impeller while the



eye bolts is being screwed down. The recommended clearance between the wear plate and the impeller is .010 to .020 inch (0,25 to 0,50 mm). Once the clearance is settled, screw the hand nuts to the fixed position

Be sure the wear plate does not scrape against the impeller.

Over time it may be necessary to repeat the adjustment process to compensate for normal wear between the impeller and wear plate. When all the adjustment has been used on the back-cover side of the pump, an additional 0.125 inch (3,2 mm) of adjustment may be obtained by removing the rotating assembly adjusting shims (63).

LUBRICATION

Allow an installed pump to completely cool before draining liquid from the pump casing. Remove the back cover. Remove the rotating assembly adjusting shims, then reinstall the hardware securing the rotating assembly to the pump casing. Perform the back-cover adjustment procedure described above to obtain the proper face clearance.


PRESSURE RELIEF VALVE MAINTENANCE

The back cover is equipped with a pressure relief valve (not shown) to provide additional safety for the pump and operator (refer to **Liquid Temperature and Overheating in OPERATION**).

It is recommended that the pressure relief valve assembly be replaced at each overhaul, or any time the pump overheats and activates the valve. **Never** replace this valve with a substitute which has not been specified or provided by the TORO Company.

Final Pump Assembly

Install the shaft key (23, Figure 8) and reconnect the power source. Be sure to install any guards used over the rotating members.



Do not operate the pump without the guards in place over the rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel.

Install the suction and discharge lines and open all valves. Make certain that all piping connections are tight, properly supported and secure.

Be sure the pump and power source have been properly lubricated, see **LUBRICATION**.

Remove the fill cover assembly (17) and fill the pump casing with clean liquid. Reinstall the fill cover and tighten it. Refer to **OPERATION**, Section C, before putting the pump back into service.

Seal Assembly

Before starting the pump, remove the vented plug (10) and fill the seal cavity with approximately 92 ounces (2,7 liters) of SAE No. 30 non-detergent oil to the middle of the sight gauge (14) and maintain it at the middle of the gauge. Clean and reinstall the vented plug. Maintain the oil at this level.

Bearings

The bearing housing was fully lubricated when shipped from the factory. Check the oil level regularly through the sight gauge (14A) and maintain it at the middle of the gauge. When lubrication is re- quired, add SAE No. 30 non-detergent oil through the hole for the air vent (11). **Do not** over-lubricate. Over-lubrication can cause the bearings to ~~over~~ heat, resulting in premature bearing failure.

Under normal conditions, drain the bearing housing once each year and refill with approximately 16 ounces (0,5 liter) of clean oil. Change the oil more frequently if the pump is operated continuously or installed in an environment with rapid temperature change.

Monitor the condition of the bearing lubricant regularly for evidence of rust or moisture condensation. This is especially important in areas where variable hot and cold temperatures are common.

For cold weather operation, consult the factory or a lubricant supplier for the recommended grade of oil.

Power Source

Consult the literature supplied with the power source, or contact your local power source representative



AUSTRALIAN DISTRIBUTOR



1300 1 GLOBAL
sales@globalpumps.com.au
globalpumps.com.au