

## **Installation and operation**

## Installation of the telescopic suction tube

Firmly screw the telescopic suction tube into the female thread of the lower part of the pump body. Extend telescopic suction tube to required length and firmly tighten wing nut.

## **Installation and Commissioning**

Connect the drum adapter of the hand pump (male thread 2") that is located at the lower part of the pump body to your drum. For plastic drums and canisters adapters can be supplied. Push the handle several times very fast and very strong up and down to build-up water a water column. A minimum level of 12-15 cm in the container is necessary for the suction process.

Never use this hand operated pump for flammable liquids and solvents or hazard class AI, AII

Comply to all safety instructions and wear necessary protective clothing (protective, glasses, gloves, apron and possibly boots).

